



Cricut[®] Machine Tips & Tricks

Machine settings for various consumables

| Material | Blade & Housing Used | Machine Settings | |
|---|----------------------|---|------------------------------|
| Magnet 0.035"/0.88 mm thick | • Deep Cut | Speed Pressure Blade depth Multi/Cut | 3 Med. 5 Max. 6 4 |
| Stencil 0.0155"/0.40 mm thick | • Standard | Speed Pressure Blade depth Multi/Cut | 3 Med. 5 Max. 6 2 |
| Notes: Adhesive is repositionable. Retain and replace liner for protecting the adhesive during storage. | | | |
| Chipboard 0.059"/1.50 mm thick | • Deep Cut | Speed Pressure Blade depth Multi/Cut | 3 Med. 4 High 6 5 |
| Notes: A fresh mat is needed to hold the material; small pieces of chipboard or if the mat is used, may require taping the chipboard in place. | | | |
| Iron-on Fabric 0.023"/0.58 mm thick | • Standard | Speed Pressure Blade depth Multi/Cut | 3 Med. 4 High 5 1 |
| Notes: Use a normal household iron at it's highest temperature setting applying direct heat and pressure for approximately 30 seconds. Cold peel. Wash and dry garment inside out. | | | |
| Emboss 0.0160"/0.41 mm thick | • Standard | Speed Pressure Blade depth Multi/Cut | 3 Med. 5 Max. 6 2 |
| Stamp 0.0415"/1.05 mm thick | • Deep Cut | Speed Pressure Blade depth Multi/Cut | 3 Med. 4 High 4.5 1 |
| Notes: A fresh mat is needed to keep the material held firmly in place. | | | |